

SELECTION DES PROGRAMMES
programmes simples 1 à 32

N°	ANIMATION	6	5	4	3	2	1
01	CLIGNOTEUR SIMPLE (1+2+3+4)	ON	ON	ON	ON	ON	ON
02	CLIGNOTEUR SIMPLE (1+2+3+4) LENT	ON	ON	ON	ON	ON	OFF
03	CLIGNOTEUR INVERSEUR (1+3) (2+4)	ON	ON	ON	ON	OFF	ON
04	CLIGNOTEUR INVERSEUR (1+3) (2+4) LENT	ON	ON	ON	ON	OFF	OFF
05	CHEF D'ORCHESTRE (1+2) (3+4)	ON	ON	ON	OFF	ON	ON
06	CHENILLARD POSITIF 4 VOIES	ON	ON	ON	OFF	ON	OFF
07	CHENILLARD POSITIF 3 VOIES	ON	ON	ON	OFF	OFF	ON
08	CHENILLARD POSITIF 4 VOIES 2 SENS	ON	ON	ON	OFF	OFF	OFF
09	CHENILLARD POSITIF 3 VOIES 2 SENS	ON	ON	OFF	ON	ON	ON
10	CHENILLARD POSITIF + CLIGNOTANT 4 VOIES	ON	ON	OFF	ON	ON	OFF
11	CHENILLARD POSITIF + CLIGNOTANT 3 VOIES	ON	ON	OFF	ON	OFF	ON
12	CHENILLARD NEGATIF 4 VOIES	ON	ON	OFF	ON	OFF	OFF
13	CHENILLARD NEGATIF 3 VOIES	ON	ON	OFF	OFF	ON	ON
14	CHENILLARD NEGATIF 4 VOIES 2 SENS	ON	ON	OFF	OFF	ON	OFF
15	CHENILLARD NEGATIF 3 VOIES 2 SENS	ON	ON	OFF	OFF	OFF	ON
16	CHENILLARD NEGATIF + CLIGNOTANT 4 VOIES	ON	ON	OFF	OFF	OFF	OFF
17	CHENILLARD NEGATIF + CLIGNOTANT 3 VOIES	ON	OFF	ON	ON	ON	ON
18	CHENILLARD MIXTE 4 VOIES	ON	OFF	ON	ON	ON	OFF
19	CHENILLARD MIXTE 3 VOIES	ON	OFF	ON	ON	OFF	ON
20	RIDEAU TYPE A 4 VOIES	ON	OFF	ON	ON	OFF	OFF
21	RIDEAU TYPE A 3 VOIES	ON	OFF	ON	OFF	ON	ON
22	RIDEAU TYPE B 4 VOIES	ON	OFF	ON	OFF	ON	OFF
23	RIDEAU TYPE B 3 VOIES	ON	OFF	ON	OFF	OFF	ON
24	RIDEAU TYPE A + CLIGNOTANT 4 VOIES	ON	OFF	ON	OFF	OFF	OFF
25	RIDEAU TYPE A + CLIGNOTANT 3 VOIES	ON	OFF	OFF	ON	ON	ON
26	RIDEAU CLIGNOTANT 4 VOIES	ON	OFF	OFF	ON	ON	OFF
27	RIDEAU CLIGNOTANT 3 VOIES	ON	OFF	OFF	ON	OFF	ON
28	EMPILAGE 4 VOIES	ON	OFF	OFF	ON	OFF	OFF
29	EMPILAGE 3 VOIES	ON	OFF	OFF	OFF	ON	ON
30	EMPILAGE + CLIGNOTANT 4 VOIES	ON	OFF	OFF	OFF	ON	OFF
31	EMPILAGE + CLIGNOTANT 3 VOIES	ON	OFF	OFF	OFF	OFF	ON
32	RESERVE PROGRAMME SPECIAL	ON	OFF	OFF	OFF	OFF	OFF

03.01

Mise en fixe : par contact à fermeture à placer à l'extérieur (potentiel phase)

ATTENTION : Cet appareil comporte une protection aval par fusibles dont la valeur est calculée pour couvrir tous les cas d'animation rapide sur charges complexes (transformateurs haute tension). En conséquence, il est impératif de prévoir une protection amont adaptée à la puissance nominale de l'appareil.

PROMOTION ELECTRONIQUE zi les carreaux 77440 Lizy-sur-Ourcq France

tél. 01 60 61 53 00 fax 01 60 61 22 24

www.promoelec.com e-mail : contact@promoelec.com

SELECTION DES PROGRAMMES
programmes complexes 33 à 64

N°	ANIMATION	6	5	4	3	2	1
33	CROIX - LOGO N° 1 4 VOIES	OFF	ON	ON	ON	ON	ON
34	CROIX - LOGO N° 1 3 VOIES	OFF	ON	ON	ON	ON	OFF
35	CROIX - LOGO N° 2 4 VOIES	OFF	ON	ON	ON	OFF	ON
36	CROIX - LOGO N° 2 3 VOIES	OFF	ON	ON	ON	OFF	OFF
37	CROIX - LOGO N° 3 4 VOIES	OFF	ON	ON	OFF	ON	ON
38	CROIX - LOGO N° 3 3 VOIES	OFF	ON	ON	OFF	ON	OFF
39	CROIX - LOGO N° 4 4 VOIES	OFF	ON	ON	OFF	OFF	ON
40	CROIX - LOGO N° 4 3 VOIES	OFF	ON	ON	OFF	OFF	OFF
41	CROIX - LOGO N° 5 4 VOIES	OFF	ON	OFF	ON	ON	ON
42	CROIX - LOGO N° 5 3 VOIES	OFF	ON	OFF	ON	ON	OFF
43	CROIX - LOGO N° 6 4 VOIES	OFF	ON	OFF	ON	OFF	ON
44	CROIX - LOGO N° 6 3 VOIES	OFF	ON	OFF	ON	OFF	OFF
45	CROIX - LOGO N° 7 4 VOIES	OFF	ON	OFF	OFF	ON	ON
46	CROIX - LOGO N° 7 3 VOIES	OFF	ON	OFF	OFF	ON	OFF
47	CROIX - LOGO N° 3 4 VOIES SANS FLASH	OFF	ON	OFF	OFF	OFF	ON
48	CROIX - LOGO N° 3 3 VOIES SANS FLASH	OFF	ON	OFF	OFF	OFF	OFF
49	ENCHAINEMENT PROGRAMMES 33 + 35 4 VOIES	OFF	OFF	ON	ON	ON	ON
50	ENCHAINEMENT PROGRAMMES 37 + 39 4 VOIES	OFF	OFF	ON	ON	ON	OFF
51	ENCHAINEMENT PROGRAMMES 34 + 36 3 VOIES	OFF	OFF	ON	ON	OFF	ON
52	ENCHAINEMENT PROGRAMMES 38 + 40 3 VOIES	OFF	OFF	ON	ON	OFF	OFF
53	ENCHAINEMENT PROGRAMMES 8+1+3+1 4 VOIES	OFF	OFF	ON	OFF	ON	ON
54	ENCHAINEMENT PROGRAMMES 14+1+3+1 4 VOIES	OFF	OFF	ON	OFF	ON	OFF
55	ENCHAINEMENT PROGRAMMES 20+22+1 4 VOIES	OFF	OFF	ON	OFF	OFF	ON
56	ENCHAINEMENT PROGRAMMES 8+14 4 VOIES	OFF	OFF	ON	OFF	OFF	OFF
57	ENCHAINEMENT PROGRAMMES 9+1+3+1 3 VOIES	OFF	OFF	OFF	ON	ON	ON
58	ENCHAINEMENT PROGRAMMES 15+1+3+1 3 VOIES	OFF	OFF	OFF	ON	ON	OFF
59	ENCHAINEMENT PROGRAMMES 21+23+1 3 VOIES	OFF	OFF	OFF	ON	OFF	ON
60	ENCHAINEMENT PROGRAMMES 9+15 3 VOIES	OFF	OFF	OFF	ON	OFF	OFF
61	RESERVE PROGRAMME SPECIAL	OFF	OFF	OFF	OFF	ON	ON
62	RESERVE PROGRAMME SPECIAL	OFF	OFF	OFF	OFF	ON	OFF
63	RESERVE PROGRAMME SPECIAL	OFF	OFF	OFF	OFF	OFF	ON
64	RESERVE PROGRAMME SPECIAL	OFF	OFF	OFF	OFF	OFF	OFF

Mise en fixe : par contact à fermeture à placer à l'extérieur (potentiel phase)

ATTENTION : Cet appareil comporte une protection aval par fusibles dont la valeur est calculée pour couvrir tous les cas d'animation rapide sur charges complexes (transformateurs haute tension). En conséquence, il est impératif de prévoir une protection amont adaptée à la puissance nominale de l'appareil.

PROMOTION ELECTRONIQUE zi les carreaux 77440 Lizy-sur-Ourcq France

tél. 01 60 61 53 00 fax 01 60 61 22 24

www.promoelec.com e-mail : contact@promoelec.com